



# X. WIRING AND SCHEMATIC DIAGRAMS, PARTS LISTS



## AUXILIARY LAMP DRIVER BOARD (A11) COMPONENT LOCATION



## AUXILIARY LAMP DRIVER BOARD (A11) PARTS LIST

PART NUMBER	DESCRIPTION	REFERENCE
ASSEMBLY	AUXILIARY LAMP DRIVER	
MA-789	ASSEMBLY	
XO-626	CAPACITOR, 1 MFD, 100V	C1
XO-202	CERAMIC RADIAL LEAD	C2-C3
XO-227	CAPACITOR, 47 MFD, 10V	C4
XO-148	ELECTROLYTIC RADIAL LEAD	Q1-Q10
	TRANSISTOR, NSD-U45	H1, H2
	NPN DARLINGTON	H2-H11
XO-23	RESISTOR, 3K OHM, 5%, 1/4 W	H1, H2
XO-9	RESISTOR, 12K OHM, 5%, 1/4W	H2-H11
XO-669	RESISTOR, 680K OHM, 5%, 1/4W	H1, H2
XO-420	I.C. 2-INPUT NAND, 7400	U1
XO-403	I.C. INVERTER, 7405	U2, U6
XO-425	I.C. DECADE COUNTER, 7490	U3
XO-426	I.C. DECODER, 7442	U4
XO-631	I.C. TIMER, NE555	U5
XO-878	10 POS. CONNECTOR	U6
XO-879	4 POS. CONNECTOR	Q1-Q10