

SERVICE INSTRUCTIONS 1

ASSY GAME ELECTRONICS ASTRO BLASTER

SELF-TEST SW.



ケースの中に下記の IC BOARD が入っています。

The following IC BOARD are provided in the case shown below.



TABLE ONLY

WIDE TYPE, 41 TYPE

USA

JAPAN, ENGLISH

JAPAN, JAPANESE

ENGLAND

FRANCE

GERMAN

834-0004
834-0017
834-0026

834-0000

834-0008

834-0025
834-0018

834-0011
834-0019

834-0014
834-0020

① ASSY CPU BOARD ASTRO BLASTER

834-0005

834-0002

800-3143

② ASSY VIDEO I BOARD

800-0106

③ ASSY 7116 PROM BOARD AB

834-0007

834-0001

834-0010

800-3142

834-0012

834-0015

④ ASSY SPEECH BOARD AB

800-3144

834-0009

800-3144

834-0013

834-0016

⑤ ASSY AB SOUND BOARD

800-3122

SPEECH & SOUND BALANCE VOLUME



DIP スイッチの調整はケースのふたをはずし ① の CPU ボードを抜き出して行って下さい。

(注: 電源は必ず切っておくこと)

Remove the cover of the case and pull out CPU board ① when making adjustments of the DIP switch.

(Caution: Always turn off the power before making this adjustment.)